



*\* The VarioBarrier requires a Straight Headrest Post and 1.75" between the Top of the Seat and the Bottom of the Head Rest for Installation. VarioBarrier will not work with curved or angled Headrest Posts. In this case, please use our VarioBarrier instead of the VarioBarrier HR.*

*Please note that a Combination of a VarioGate + VarioBarrier is Recommended for the Best Crash Safety.*